


# 2D handheld barcode scanner User Manual



This User manual is quick start manual. For detailed manual information, please download the completed user manual from our website or obtain it from our distributor.

## Factory Default



Note: Default interface: USB-KBW

## Setting Procedure:

Scan required bar codes

Eg: Factory default, USB-KBW, add suffix "Enter" etc bar codes as below

1. Factory Default



2. Enter



## Interfaces:



USB-KBW



USB-COM



USB-POS

## Scan Mode:



Manual



Continuous



Auto-induction

## Inverted Image Reading



Enable Inverted image



Disable Inverted image

## Illumination



General  
(light on when reading)



Continuous



None

## Sound Setting



OFF



ON



Low



High

## Keyboard Language



USA



UK



French



Russia

## Character Conversion



None



All Capital



All lowercase

## Suffix Setting



Enter



Enter & Line feed



TAB



Cancel

## Baud Rate Setting (RS232 interfaces)



4800



9600



19200



38400



57600



115200

Barcodes Setting

	Enable ISBN		Disable Matrix 2 of 5		Enable RSS-14
	Disable all Barcodes		Disable ISBN		Enable Industrial 25
	Enable all barcodes		Enable UPC-E		Disable Industrial 25
	Enable Code 128		Disable UPC-E		Enable Standard 25
	Disable Code 128		Enable UPC-A		Disable Standard 25
	Enable UCC/EAN-128		Disable UPC-A		Enable Code 39
	Disable UCC/EAN-128		Enable Interleaved 2 of 5		Disable Code 39
	Enable AIM 128		Disable Interleaved 2 of 5		Enable Code 93
	Disable AIM 128		Enable ITF-6 no output check digit		Disable Code 93
	Enable EAN-8		Enable ITF-6 output check digit		Enable Code 11
	Disable EAN-8		Disable ITF-6		Disable Code 11
	Enable EAN-13		Enable ITF-14 no output check digit		Enable Plessey
	Disable EAN-13		Enable ITF-14 output check digit		Disable Plessey
	Enable ISSN		Disable ITF-14		Enable MSI-Plessey
	Disable ISSN		Enable Matrix 2 of 5		Disable MSI-Plessey